

How-To Request a Dicing Blade Change



This procedure describes the process required to specify or request a specific blade (other than the default glass blade) for the Disco DAD 3240 Dicing Saw. In order to ensure that there is sufficient time to restore the default glass blade, you **must** complete your session at least 30 minutes before the end of regular business hours (typically 5 pm).

Equipment	Disco DAD 3240 Dicing Saw
Process Area	PACKAGING
Location	W1-060

Step-By-Step Guide

1. [Create an LMACS request](#)
 - a. Enter **Dicing Blade Change** for the Title.
 - b. Select the **Equipment Configuration** Type.
 - c. Select **Dicing Saw (Disco DAD 3240)** for the Equipment.
 - d. In the **Summary**, enter the desired blade type (e.g., Si blade, sapphire blade).
2. Add a new **Booking** within the request, selecting the **Dicing Saw (Disco DAD 3240)**.
 - a. Add an additional 30 mins to the beginning and end of your processing time to allow for the blade changes.
 - b. A nanoFAB staff member will change the blade during these additional 30 minute slots.
3. Once the blade has been changed, you will be able to begin your dicing.
 - a. Ensure you give at least 24 hrs for a blade change request.
4. Login and use the system as usual and you will be billed for the actual used time.